

MT20 Spare Parts List

NO.	PART NUMBER	DESCRIPTION	LOCATION		QTY.
1	Z90-43940-00	BRG(LN)	BED	W04-1000-004	1
2	Z90-44483-00	BRG(LN)	BED	W04-1000-006	1
3	Z90-44484-00	BRG(LN)	BED	W04-1000-007	1
4	ZK9-20731-00	BRG(TR)	OPERATION BOX	W04-1200-019	2
5	ZK9-21543-00	BRG(ND)	OPERATION BOX	W04-1200-021	2
6	Z06-21073-10	BRG(ND)	OPERATION BOX	W04-1200-022	4
7	ZV1-00228-00	BRG(LN)	COVER	W04-1300-059	2
8	Z06-62609-10	LAMP(FL)	COVER	W04-1300-060	2
9	W04-13320-60	WIPER(LZ)	COVER	W04-1300-067	1
10	W04-13720-61	WIPER(LZ2)	COVER	W04-1300-068	1
11	W04-13730-60	WIPER(LZ1)	COVER	W04-1300-069	1
12	W04-13740-61	WIPER(RZ3)	COVER	W04-1300-070	1
13	W04-13750-60	WIPER(RZ1)	COVER	W04-1300-071	1
14	W04-13760-60	WIPER(RZ2)	COVER	W04-1300-072	1
15	ZV1-00228-00	BRG(LN)	DOOR(L)	W04-1310-011	4
16	Z07-05302-30	BRG(RB)	DOOR(L)	W04-1310-012	4
17	Z06-87861-80	CBL-CHAIN	DOOR(L)	W04-1310-015	1
18	Z07-31450-00	AIR-CYL	DOOR(L)	W04-1310-017	1
19	Z06-90102-40	C-VLV(A-SOL)	DOOR(L)	W04-1310-019	1
20	W04-13970-60	WIPER	DOOR(L)	W04-1310-024	1
21	ZV1-00228-00	BRG(LN)	DOOR(R)	W04-1321-011	4
22	Z07-05302-30	BRG(RB)	DOOR(R)	W04-1321-012	4
23	Z07-03651-00	CBL-CHAIN	DOOR(R)	W04-1321-015	1
24	Z07-31450-00	AIR-CYL	DOOR(R)	W04-1321-017	1
25	Z06-90102-40	C-VLV(A-SOL)	DOOR(R)	W04-1321-019	1
26	W04-13980-60	WIPER	DOOR(R)	W04-1321-024	1
27	W04-15170-62	WIPER(L)	CENTER SHUTTER	W04-1330-015	1
28	W04-15180-62	WIPER(R)	CENTER SHUTTER	W04-1330-016	1
29	ZV1-00380-00	BRG(RB)	CENTER SHUTTER	W04-1330-026	2
30	Z01-10819-00	BRG(RB)	CENTER SHUTTER	W04-1330-027	1
31	Z06-25798-20	BRG(LN)	CENTER SHUTTER	W04-1330-030	2
32	Z06-88221-60	BRG(LN)	CENTER SHUTTER	W04-1330-031	1
33	Z07-94150-00	AIR-CYL	CENTER SHUTTER	W04-1330-032	1
34	Z06-03984-50	AIR-CYL-P	CENTER SHUTTER	W04-1330-033	1
35	MB0-18150-60	BUSH(DU)	CENTER SHUTTER	W04-1330-035	2
36	Z06-90101-60	C-VLV(A-SOL)	CENTER SHUTTER	W04-1330-037	1
37	Z07-49479-00	SW(PRX)	RAIL&SW	W04-1340-006	2
				Sub-Total of Group A	
38	Z90-65870-00	CYLINDER, HYD.	SPINDLE		1
39	W04-20010-61	HEAD STOCK	SPINDLE	W04-2010-001	2
40	W04-20020-51	SPINDLE S.A.	SPINDLE	W04-2010-002	2
41	Z90-56042-00	BRG(RR)	SPINDLE	W04-2010-003	2
42	Z90-52459-00	BRG(ANG)	SPINDLE	W04-2010-004	2
43	Z90-56041-00	BRG(RR)	SPINDLE	W04-2010-005	2
44	ZV2-00463-00	BRG-RTNR	SPINDLE	W04-2010-006	2
45	ZK5-90018-00	RING(O)	SPINDLE	W04-2010-007	2
46	5000-1073	BUTTON, DRIVE	SPINDLE	W04-2010-008	2
47	MC9-20033-60	FRONT CLOSURE	SPINDLE	W04-2010-009	2
48	Z06-25925-00	RING(O)	SPINDLE	W04-2010-010	2
49	Z06-42142-10	PCKNG	SPINDLE	W04-2010-011	2
50	W04-20030-62	FRONT CLOSER SEAL	SPINDLE	W04-2010-012	2
51	A08-20180-60	LABYRINTH RING	SPINDLE	W04-2010-013	2
52	W0-420050-60	SPACER	SPINDLE	W04-2010-014	2
53	W03-20070-60	REAR CLOSER	SPINDLE	W04-2010-015	2
54	A08-20210-60	LABYRINTH RING	SPINDLE	W04-2010-016	2
55	A08-20200-60	SPACER	SPINDLE	W04-2010-017	2
56	W04-20040-61	V-PULLEY	SPINDLE	W04-2010-018	2
57	W03-20230-60	KEY	SPINDLE	W04-2010-020	2
58	MS720060-60	DRAIN POCKET	SPINDLE	W04-2010-021	2
59	Z07-96283-00	BLT(V)	SPINDLE DRIVE(L)	W04-2110-003	1
60	Z07-48359-00	BLT(V)	SPINDLE DRIVE(R)	W04-2120-003	1
61	Z90-44073-00	CBL-CHAIN	CROSS SLIDE(L)	W04-3011-014	1
62	Z90-44074-00	CBL-CHAIN	CROSS SLIDE(L)	W04-3011-015	1
63	Z90-44073-00	CBL-CHAIN	CROSS SLIDE(R)	W04-3021-014	1
64	Z90-44074-00	CBL-CHAIN	CROSS SLIDE(R)	W04-3021-015	1
65	Z90-43942-00	BALL-SCRW	X-AXIS DRIVE	W04-3101-008	2
66	Z90-44005-00	BRAKE	X-AXIS DRIVE	W04-3101-009	2
67	Z90-49569-00	CPLNG	X-AXIS DRIVE	W04-3101-010	2
68	Z07-04007-00	BRG(ANG)	X-AXIS DRIVE	W04-3101-011	4
69	Z06-4748-10	OSL	X-AXIS DRIVE	W04-3101-013	2
70	Z9043938-00	BRG(LN)	LX BASE(WITHOUT Y)	W04-3111-003	1
71	Z90-43938-00	BRG(LN)	RX BASE(WITHOUT Y)	W04-3121-003	1

MT20 Spare Parts List

NO.	PART NUMBER	DESCRIPTION	LOCATION		QTY.
72	Z90-43944-00	BALL-SCRW	LZ-AXIS DRIVE	W04-3210-006	1
73	Z90-44002-00	CPLNG	LZ-AXIS DRIVE	W04-3210-007	1
74	Z07-28815-00	BRG(ANG)	LZ-AXIS DRIVE	W04-3210-008	1
75	Z07-04007-00	BRG(ANG)	LZ-AXIS DRIVE	W04-3210-009	1
76	Z06-47480-10	OSL	LZ-AXIS DRIVE	W04-3210-012	2
77	Z90-43945-00	BALL-SCRW	RZ-AXIS DRIVE	W04-3220-007	1
78	Z90-44002-00	CPLNG	RZ-AXIS DRIVE	W04-3220-008	1
79	Z07-28815-00	BRG(ANG)	RZ-AXIS DRIVE	W04-3220-009	1
80	Z07-04007-00	BRG(ANG)	RZ-AXIS DRIVE	W04-3220-010	1
81	Z06-47480-10	OSL	RZ-AXIS DRIVE	W04-3220-013	2
82	Z90-44067-00	CBL-CHAIN	RZ SLIDE	W04-3221-007	1
83	Z90-44068-00	CBL-CHAIN	RZ SLIDE	W04-3221-008	1
84	ZK9-20445-00	RING(O)	TURRET(L)	W04-3310-007	1
85	Z06-14164-00	RING(O)	TURRET(L)	W04-3310-008	1
86	ZK9-20445-00	RING(O)	TURRET(R)	W04-3310-007	1
87	Z06-14164-00	RING(O)	TURRET(R)	W04-3310-008	1
88	Z07-28303-00	BUSH(DU)	TURRET INDEX(L)	W04-3410-028	1
89	Z07-28304-00	BUSH(DU)	TURRET INDEX(L)	W04-3410-029	1
90	Z06-54351-A0	RING(O)	TURRET INDEX(L)	W04-3410-031	1
91	Z0728301-00	PCKNG	TURRET INDEX(L)	W04-3410-033	1
92	Z07-28302-00	PCKNG	TURRET INDEX(L)	W04-3410-034	1
93	Z07-06731-80	SCRAPER	TURRET INDEX(L)	W04-3410-035	1
94	Z90-30853-50	RING(D)	TURRET INDEX(L)	W04-3410-036	1
95	ZK5-90028-00	RING(O)	TURRET INDEX(L)	W04-3410-037	1
96	Z02-5069800	RING(O)	TURRET INDEX(L)	W04-3410-038	1
97	Z06-05138-10	BRG(RB)	TURRET INDEX(L)	W04-3410-039	1
98	ZK9-22246-00	BRG(RB)	TURRET INDEX(L)	W04-3410-040	1
99	Z06-22669-60	BRG(LN)	TURRET INDEX(L)	W04-3410-042	2
100	Z90-48300-00	SW(TCH)	TURRET INDEX(L)	W04-3410-044	2
101	Z90-43984-00	BRG(RB)	TURRET INDEX(L)	W04-3410-046	2
102	Z06-10158-30	RING(O)	TURRET INDEX(L)	W04-3410-047	1
103	Z07-10098-60	RING(O)	TURRET INDEX(L)	W04-3410-048	1
104	Z07-53997-00	RING(BK-UP)	TURRET INDEX(L)	W04-3410-053	1
105	Z07-28303-00	BUSH(DU)	TURRET INDEX(R)	W04-3420-028	1
106	Z07-28304-00	BUSH(DU)	TURRET INDEX(R)	W04-3420-029	1
107	Z06-54351-A0	RING(O)	TURRET INDEX(R)	W04-3420-031	1
108	Z07-28301-00	PCKNG	TURRET INDEX(R)	W04-3420-033	1
109	Z07-28302-00	PCKNG	TURRET INDEX(R)	W04-3420-034	1
110	Z07-06731-80	SCRAPER	TURRET INDEX(R)	W04-3420-035	1
111	Z90-30853-50	RING(D)	TURRET INDEX(R)	W04-3420-036	1
112	ZK5-90028-00	RING(O)	TURRET INDEX(R)	W04-3420-037	1
113	Z02-50698-00	RING(O)	TURRET INDEX(R)	W04-3420-038	1
114	Z06-05138-10	BRG(RB)	TURRET INDEX(R)	W04-3420-039	1
115	ZK9-22246-00	BRG(RB)	TURRET INDEX(R)	W04-3420-040	1
116	Z06-22669-60	BRG(LN)	TURRET INDEX(R)	W04-3420-042	2
117	Z90-48300-00	SW(TCH)	TURRET INDEX(R)	W04-3420-044	2
118	Z90-43984-00	BRG(RB)	TURRET INDEX(R)	W04-3420-046	2
119	Z06-10158-30	RING(O)	TURRET INDEX(R)	W04-3420-047	1
120	Z07-10098-60	RING(O)	TURRET INDEX(R)	W04-3420-048	1
121	Z07-53997-00	RING(BK-UP)	TURRET INDEX(R)	W04-3420-053	1
122	Z07-52085-00	SW(PH)	UNLOAD CHUTE(L)	W04-4610-010	1
123	Z07-52085-00	SW(PH)	UNLOAD CHUTE(R)	W04-4620-010	1
124	Z06-07862-00	BRG(RB)	L/R-AXIS DRIVE	W04-5111-008	3
125	Z06-58424-00	BRG(CF)	L/R-AXIS DRIVE	W04-5111-011	2
126	Z06-58267-10	BRG(CF)	L/R-AXIS DRIVE	W04-5111-012	2
127	Z06-98528-70	CBL-CHAIN	L/R-AXIS DRIVE	W04-5111-020	1
128	Z07-61060-00	CBL-CHAIN	L/R-AXIS DRIVE	W04-5111-022	1
129	Z90-34858-50	MNFLD-A-ASSY	L/R-AXIS DRIVE	W04-5111-023	1
130	Z90-30834-50	BRG(LN)	L/R-AXIS DRIVE	W04-5111-024	2
131	Z06-61390-80	BRG(RB)	F/B-AXIS DRIVE	W04-5210-003	2
132	Z90-30835-50	BRG(LN)	F/B-AXIS DRIVE	W04-5210-015	1
133	Z90-53803-00	BRG(LN)	U/D-AXIS DRIVE	W04-5311-002	1
134	Z06-61390-80	BRG(RB)	U/D-AXIS DRIVE	W04-5311-004	2
135	Z06-07862-00	BRG(RB)	U/D-AXIS DRIVE	W04-5311-005	1
136	Z06-07862-00	BRG(RB)	WRIST DRIVE	W04-5400-009	1
137	Z07-31194-00	MOTOR(GR)	WRIST DRIVE	W04-5400-010	1
				Sub-Total of Group B	
138	MC8-51378-60	RACK(X)	RAIL	W04-5512-007	1
139	MC8-51370-60	RACK(X)	RAIL	W04-5512-008	1
140	Z90-36798-50	BRG(LN)	RAIL	W04-5512-012	1
141	Z07-56923-00	CBL-CHAIN	RAIL	W04-5512-015	1
142	W04-56001-40	LODER HEAD(270)	LODER HEAD(270)	W04-5601	1

MT20 Spare Parts List

NO.	PART NUMBER	DESCRIPTION	LOCATION		QTY.
143	W02-56010-61	HOUSING	LODER HEAD(270)	W04-5601-001	1
144	W02-56021-61	TURRET(CAM)	LODER HEAD(270)	W04-5601-002	1
145	W02-56030-60	PIN	LODER HEAD(270)	W04-5601-003	7
146	W02-56031-60	PIN	LODER HEAD(270)	W04-5601-004	1
147	Z06-86508-70	BRG(RF)	LODER HEAD(270)	W04-5601-005	8
148	Z06-07863-80	BRG(RB)	LODER HEAD(270)	W04-5601-006	1
149	W02-56040-60	SPACER 8T	LODER HEAD(270)	W04-5601-007	2
150	W02-56050-60	RETAINER	LODER HEAD(270)	W04-5601-008	1
151	Z06-07864-60	BRG(RB)	LODER HEAD(270)	W04-5601-009	1
152	W04-56010-60	ADAPTER	LODER HEAD(270)	W04-5601-010	1
153	Z06-86510-A0	OSL	LODER HEAD(270)	W04-5601-011	1
154	W02-56070-60	SHAFT	LODER HEAD(270)	W04-5601-012	1
155	W02-56081-60	CAM	LODER HEAD(270)	W04-5601-013	2
156	W02-56090-61	NUT	LODER HEAD(270)	W04-5601-014	1
157	W04-56020-61	GEAR	LODER HEAD(270)	W04-5601-015	1
158	W02-56110-60	HOUSING	LODER HEAD(270)	W04-5601-016	1
159	ZK1-02201-00	BRG(RB)	LODER HEAD(270)	W04-5601-017	2
160	Z06-86741-10	SW(PRX)	LODER HEAD(270)	W04-5601-018	3
161	Z06-86740-30	SW(PRX)-P	LODER HEAD(270)	W04-5601-019	3
162	W02-56120-60	SUPPORT	LODER HEAD(270)	W04-5601-020	1
163	W02-56131-60	DOG	LODER HEAD(270)	W04-5601-021	1
164	W02-56141-60	DOG	LODER HEAD(270)	W04-5601-022	1
165	W02-56150-60	SUPPORT	LODER HEAD(270)	W04-5601-023	1
166	Z06-2020880	JOINT(ELBOW)	LODER HEAD(270)	W04-5601-024	4
167	W02-56160-60	COVER	LODER HEAD(270)	W04-5601-025	1
168	W02-56170-60	COVER	LODER HEAD(270)	W04-5601-026	2
169	Z05-50010-00	GN GN(A) M6F(P=1.0)	LODER HEAD(270)	W04-5601-027	1
170	Z90-34189-50	OIL-LBR	LUB.SYS.(WITHOUT Y)	W04-6001-001	1
171	Z90-34484-50	OIL-LBR	LOADER LUB.SYS.	MC8-6010-001	1
172	Z06-89489-30	PUMP(CLNT)	COOLANT	W04-6300-001	2
173	Z07-42072-00	PUMP(CLNT)	COOLANT	W04-6300-001	2
174	Z06-90839-80	C-VLV(A-SOL)	COOLANT	W04-6300-010	4
175	Z06-90839-80	C-VLV(A-SOL)	CENTER COOLANT(L)	W03-6310-001	1
176	Z06-90839-80	C-VLV(A-SOL)	CENTER COOLANT(R)	W03-6320-001	1
177	Z07-62758-00	PUMP(CLNT)	COOLANT FLASHING	W04-6330-022	1
178	ZR5-00962-00	SW(PR)	AIR SYS.(G/L)	W03-6410-002	1
179	Z06-57806-10	MNFLD-A-ASSY	AIR SYS.(G/L)	W03-6410-003	1
180	Z06-57807-00	MNFLD-A-ASSY	AIR SYS.(G/L)	W03-6410-004	2
181	Z06-57808-80	MNFLD-A-ASSY	AIR SYS.(G/L)	W03-6410-005	1
182	Z06-57809-60	MNFLD-A-ASSY	AIR SYS.(G/L)	W03-6410-006	1
183	Z07-00711-10	C-VLV(A-SOL)	AIR SYS.(G/L)	W03-6410-012	2
184	Z07-06765-20	SW(PR)	WORK LOCATION	W02-6421-001	2
185	Z07-00711-10	C-VLV(A-SOL)	CENTER AIR BLOW	W03-6430-001	2
186	Z90-42031-00	MNFLD-H-ASSY	HYD.SYS.	W04-6500-002	2
187	Z90-42032-00	MNFLD-H-ASSY	HYD.SYS.	W04-6500-003	2
188	Z07-47330-00	SW(PR)	HYD.SYS.HOSE	W04-6510-002	2
189	Z06-73661-A0	FAN	T.D.COMP	W04-7101-003	2
190	Z06-07863-80	BRG(RB)	PARTS CATCHER(R)	W04-7210-041	2
191	Z06-10493-10	BRG(RB)	PARTS CATCHER(R)	W04-7210-042	1
192	Z06-90102-40	C-VLV(A-SOL)	PARTS CATCHER(R)	W04-7210-044	2
193	Z07-01779-50	BRG(LN)	PARTS CATCHER(R)	W04-7210-045	1
194	Z07-02260-80	BRG(ND)	PARTS CATCHER(R)	W04-7210-047	1
195	Z07-02833-A0	AIR-CYL-P	PARTS CATCHER(R)	W04-7210-048	1
196	Z07-04102-50	AIR-CYL	PARTS CATCHER(R)	W04-7210-049	1
197	ZK1-01304-00	BRG(RB)	PARTS CATCHER(R)	W04-7210-051	2
198	Z07-29115-00	CBL-CHAIN	PARTS CATCHER(R)	W04-7210-053	1
199	Z07-31270-01	AIR-CYL	PARTS CATCHER(R)	W04-7210-054	1
200	Z06-55133-30	BRG(RB)	P/C UNLOAD CONVEYOR	W04-7211-006	2
201	Z11-10095-00	BRG(RB)	P/C UNLOAD CONVEYOR	W04-7211-009	2
202	Z90-44398-00	BLT(STL)	P/C UNLOAD CONVEYOR	W04-7211-014	1
203	Z06-32888-00	MOTOR	P/C UNLOAD CONVEYOR	W04-7211-019	1
204	MS7-81000-10	LOADER CHUCK ASSY.	LOADER CHUCK(AB)	MS7-8100	1
205	MS7-81010-61	CHUCK HOUSING 001	LOADER CHUCK(AB)	MS7-8100-001	1
206	MC8-81222-60	CYLINDER	LOADER CHUCK(AB)	MS7-8100-002	2
207	Z07-19487-50	RING(X)	LOADER CHUCK(AB)	MS7-8100-003	2
208	Z06-01818-00	RING(O)	LOADER CHUCK(AB)	MS7-8100-004	2
209	MC8-81022-61	CAP	LOADER CHUCK(AB)	MS7-8100-005	2
210	Z06-59613-20	JOINT(NPL)	LOADER CHUCK(AB)	MS7-8100-006	4
211	MC8-81062-61	PISTON	LOADER CHUCK(AB)	MS7-8100-007	2
212	Z06-65748-40	PCKNG	LOADER CHUCK(AB)	MS7-8100-008	2
213	Z06-65764-60	WASHER	LOADER CHUCK(AB)	MS7-8100-009	2
214	MS7-81020-63	ROD(CYL)	LOADER CHUCK(AB)	MS7-8100-010	2
215	MS7-81030-60	COVER	LOADER CHUCK(AB)	MS7-8100-011	1

MT20 Spare Parts List

NO.	PART NUMBER	DESCRIPTION	LOCATION		QTY.
216	Z32-50225-00	RING(O)	LOADER CHUCK(AB)	MS7-8100-012	2
217	W04-81010-10	CHUCK GUIDE ASSY.	CHUCK GUIDE	W04-8110	1
218	W04-81070-60	GUIDE	CHUCK GUIDE	W04-8110-001	1
219	MC8-81341-60	LINK(JAW)	CHUCK GUIDE	W04-8110-002	3
220	MC8-81350-60	PIN(LINK)	CHUCK GUIDE	W04-8110-003	3
221	W04-81010-60	GUIDE	CHUCK GUIDE	W04-8110-004	1
222	W04-81020-60	GUIDE (JAW)	CHUCK GUIDE	W04-8110-005	1
223	W04-81030-60	GUIDE COVER(TOP)	CHUCK GUIDE	W04-8110-006	1
224	W04-81040-60	JAW(MASTER)	CHUCK GUIDE	W04-8110-007	3
225	W04-81051-61	PIN	CHUCK GUIDE	W04-8110-008	3
226	W04-81061-60	PUSHER PLATE	CHUCK GUIDE	W04-8110-009	1
227	Z06-70455-50	SPRNG(COIL)	CHUCK GUIDE	W04-8110-010	3
228	Z05-50010-00	GN GN(A) M6F(P=1.0)	CHUCK GUIDE	W04-8110-011	1
229	MC8-81400-60	BOLT	CHUCK GUIDE	W04-8110-012	3
230	Z90-33486-50	MNFLD-H-ASSY	HIGH-LOW CHUCK	W04-L0029-10	2
231	Z08-03340-00	OIL-CLR	OIL COOLER SYSTEM	MC8-L3101-10	1
232	Z07-51437-00	SNSR(TEMP)	OIL COOLER SYSTEM	W04-L0176-10	1
				Sub-Total of Group C	
233	Z90-60400-00	CTRL-PNL	OPE. BOX		1
234	Z90-55639-00	PCB-ASSY	CONTROL BOX		2
235	Z90-54568-00	PCB-ASSY	CONTROL BOX		6
236	Z90-53428-00	PCB-ASSY	CONTROL BOX		5
237	Z90-53429-00	PCB-ASSY	CONTROL BOX		5
238	Z90-45607-00	PCB-ASSY	CONTROL BOX		1
239	Z07-52268-00	POWER-SPPLY	CONTROL BOX		1
240	Z07-67442-00	POWER-SPPLY	CONTROL BOX		1
241	AS1-00314-50R	CABLE ASS'Y	LOADER CABLE		1
242	AS1-00324-50R	CABLE ASS'Y	LOADER CABLE		1
243	AS1-00334-50R	CABLE ASS'Y	LOADER CABLE		1
244	AS1-00344-50R	CABLE ASS'Y	LOADER CABLE		1
245	AS1-00354-50R	CABLE ASS'Y	LOADER CABLE		1
246	AS1-00364-50R	CABLE ASS'Y	LOADER CABLE		1
247	AS1-02704-50R	CABLE ASS'Y	LOADER CABLE		1
248	AS1-02713-50R	CABLE ASS'Y	LOADER CABLE		1
249	AS1-02723-50R	CABLE ASS'Y	LOADER CABLE		1
250	AS1-02730-50R	CABLE ASS'Y	LOADER CABLE		1
251	AS1-02781-50	CABLE ASS'Y	LOADER CABLE		1
				Electrical Parts	